

Lower Door Latch Assembly

With the Lower Door Closed line the latch assembly up like shown in the photo below, mark where about you need to mount the base of the latch then drill 2— $\frac{13}{64}$ th holes $\frac{3}{4}$ ” apart now fasten in place with the $\frac{10}{24}$ X $\frac{1}{2}$ ” machine screw, then put the holder back in place and mark where it needs to go making sure that there is tension on the draw latch. Then drill a $\frac{13}{64}$ th hole for the holder bracket as shown in the photo below also and bolt in place using the $\frac{10}{32}$ X $\frac{1}{2}$ ” machine screw and nylon lock nut. This is self sealing when tightened. Now repeat on the other side.

There is no set height for this Latch assembly just installers choice.

